


**Raychem** Constant Wattage  
Parallel Circuit Heating  
Cable Systems

---

INSTALLATION AND MAINTENANCE MANUAL



<b>1</b>	<b>General information</b>	<b>1</b>
<b>2</b>	<b>Heating cable selection</b>	<b>5</b>
<b>3</b>	<b>Heating cable installation</b>	<b>6</b>
<b>4</b>	<b>Components installation</b>	<b>16</b>
<b>5</b>	<b>Thermostats</b>	<b>18</b>
<b>6</b>	<b>Thermal insulation and marking</b>	<b>19</b>
<b>7</b>	<b>Power supply and electrical protection</b>	<b>21</b>
<b>8</b>	<b>Heating cable testing</b>	<b>21</b>
<b>9</b>	<b>Operation, maintenance and pipe repairs</b>	<b>23</b>
<b>10</b>	<b>Heating cable damage</b>	<b>24</b>
<b>11</b>	<b>Troubleshooting guide</b>	<b>24</b>



Special conditions for safe use:

1. The following limiting temperatures for the exposure of the end seals and splices shall not be exceeded: 180°C continuous operation and 200°C intermittent operation for the E-150-F and CS-150-F
2. The assembly of glands, splices and end terminations shall be carried out in accordance with the installation instructions
3. The heating element supply circuit must include an electrical protection device in conformity with clause 4.3 of EN/IEC 60079-30-1: 2007
4. The minimum bending radius is 25 mm for the types FMT and FHT cables
5. The supply of the heating unit must be terminated in a suitably certified terminal enclosure

	<b>FMT</b>	<b>FHT</b>
Minimum Bending Radius at Minimum Installation Temperature	25 mm	25 mm
Minimum Installation Temperature	-40°C	-60°C
Maximum Withstand Temperature (continuous, de-energised)	200°C	260°C
Temperature classification	Refer to design tables below or use Pentair design software	Refer to design tables below or use Pentair design software
Minimum clearance	50 mm	50 mm

### **Design tables for non-hazardous areas**

	Maximum allowed surface temperature [°C] (= limiter setpoint)		
	<b>230 V a.c.</b>	<b>254 V a.c.</b>	<b>277 V a.c.</b>
10FMT2-CT	158	153	144
20FMT2-CT	129	116	97
30FMT2-CT	94	71	36
10FHT2-CT	229	225	219
20FHT2-CT	209	199	187
30FHT2-CT	184	168	143
40FHT2-CT	154	130	87

Maximum allowed surface temperature (°C)  
(= limiter setpoint)

	<b>385 V a.c.</b>	<b>400 V a.c.</b>	<b>415 V a.c.</b>
10FHT4-CT	250	250	249
20FHT4-CT	224	221	218
30FHT4-CT	212	208	205

### Design tables for hazardous areas

Maximum allowed surface temperature (°C)  
(= limiter setpoint)

<b>230 V a.c.</b>	T6 (85°C)	T5 (100°C)	T4 (135°C)	T3 (200°C)	T2 (260°C)
10FMT2-CT	8	26	69	147	-
20FMT2-CT	-	-	19	109	-
30FMT2-CT	-	-	-	65	-
10FHT2-CT	8	26	69	147	225
20FHT2-CT	-	-	19	109	200
30FHT2-CT	-	-	-	65	169
40FHT2-CT	-	-	-	8	131

Maximum allowed surface temperature (°C)  
(= limiter setpoint)

<b>254 V a.c.</b>	T6 (85°C)	T5 (100°C)	T4 (135°C)	T3 (200°C)	T2 (260°C)
10FMT2-CT	-	12	56	137	-
20FMT2-CT	-	-	-	88	-
30FMT2-CT	-	-	-	23	-
10FHT2-CT	-	12	56	137	218
20FHT2-CT	-	-	-	88	185
30FHT2-CT	-	-	-	23	140
40FHT2-CT	-	-	-	-	81

<b>277 V a.c.</b>	Maximum allowed surface temperature (°C) (= limiter setpoint)				
	T6 (85°C)	T5 (100°C)	T4 (135°C)	T3 (200°C)	T2 (260°C)
10FMT2-CT	-	-	37	122	-
20FMT2-CT	-	-	-	53	-
30FMT2-CT	-	-	-	-	-
10FHT2-CT	-	-	37	122	207
20FHT2-CT	-	-	-	53	161
30FHT2-CT	-	-	-	-	90
40FHT2-CT	-	-	-	-	-

<b>385 V a.c.</b>	Maximum allowed surface temperature (°C) (= limiter setpoint)				
	T6 (85°C)	T5 (100°C)	T4 (135°C)	T3 (200°C)	T2 (260°C)
10FHT4-CT	34	52	94	171	249
20FHT4-CT	-	-	40	128	216
30FHT4-CT	-	-	-	105	202

<b>400 V a.c.</b>	Maximum allowed surface temperature (°C) (= limiter setpoint)				
	T6 (85°C)	T5 (100°C)	T4 (135°C)	T3 (200°C)	T2 (260°C)
10FHT4-CT	30	48	90	169	247
20FHT4-CT	-	-	30	121	212
30FHT4-CT	-	-	-	95	195

<b>415 V a.c.</b>	Maximum allowed surface temperature (°C) (= limiter setpoint)				
	T6 (85°C)	T5 (100°C)	T4 (135°C)	T3 (200°C)	T2 (260°C)
10FHT4-CT	25	44	87	166	246
20FHT4-CT	-	-	18	112	206
30FHT4-CT	-	-	-	82	187

## **Warning**

**As with any electrical equipment or wiring installation operating at line voltages, heating cable and component damage or incorrect installation that allows the penetration of moisture or contamination can lead to electrical tracking, arcing and potential fire hazard.**

**Do not connect heating cable conductors together or this will result in a short circuit.**

**Any unconnected heating cable end must be sealed with an approved end seal.**

**To prevent fire or explosion in hazardous areas, verify that the maximum sheath temperature of the heating cable is below the auto-ignition temperature of the gases in the area. For further information, see design documentation.**

## **2 HEATING CABLE SELECTION**

Check the design specification to make sure the proper heating cable is installed on each pipe or vessel. Refer to Pentair product literature to select the proper heating cable for each thermal, chemical, electrical and mechanical environment.

## 3 HEATING CABLE INSTALLATION

### 3.1 Heating cable storage

- Store the heating cable in a clean, dry place
- Temperature range:  $-40^{\circ}\text{C}$  to  $+60^{\circ}\text{C}$
- Protect the heating cable from mechanical damage

### 3.2 Pre-installation checks

Check materials received:

- Review the heating cable design and compare the list of materials to the catalogue numbers of heating cables and electrical components received to confirm that proper materials are on site. The heating cable type is printed on its outer jacket.
- Temperature exposure must not exceed that specified in the product literature. Exceeding these limits will impair product performance. Check that expected exposure is within these limits.
- Ensure that the heating cable voltage rating is suitable for the service voltage available. Do not energize cable when it is coiled or on the reel.
- Inspect heating cable and components for in-transit damage. An insulation resistance test (see section 8) on each reel is recommended.

Check piping to be traced:

- Ensure all pressure testing is complete and pipework has final paint coating.
- Walk the system and plan the routing of the heating cable on the pipe.
- Check pipework against specification drawing. If different consult design authority.
- Inspect piping for burrs, rough surfaces, sharp edges etc. which could damage the heating cable. Smooth off or cover with layers of glass cloth tape or aluminium foil.



### 3.3 Heating cable handling

Heating cable handling tips:

- Paint and pipe coatings must be dry to the touch before heating cable installation.
- When pulling the heating cable, **avoid**:
  - sharp edges
  - excessive pulling force
  - kinking and crushing
  - walking on it, or running over it with equipment

Heating cable pulling tips:

- Use a reel holder that pays out smoothly with little tension.
- Keep heating cable strung loosely but close to the pipe being traced to avoid interference with supports and equipment.
- Pay out designed length and mark (i.e. with fixing tape) on cable while still on reel.
- Leave the appropriate amount of heating cable at all power connection, splice, tee and end seal locations. (Refer to component installation instructions)
- Add additional heating cable to trace the fittings and supports or for spiralling as required by the design specifications.
- Protect all heating cable ends from moisture, contamination and mechanical damage or other interference if left exposed before component installation.


### 3.4 Heating cable attachment recommendations

- The heating cable may be installed straight, spiralled or in multiple runs as required by the design specification.
- **Do not** use metal attachments, vinyl electrical tape or duct tape as heating cable damage may result.
- Fix in place with a minimum of two wraps of the appropriate self-adhesive glass cloth tape (see figure 1) or plastic cable ties at 300 mm intervals and additionally where necessary.
- Plastic cable ties must have a temperature rating that matches the system exposure temperature.
- The heating cable's minimum bend radius must not be exceeded (refer to p. 2)  
The heating cable's minimum spacing between turns must not be exceeded (refer to p. 2)

#### 3.4.1 Straight tracing

- Straight trace the pipe unless the design calls for spiralling (see 3.4.2).
- On horizontal pipes fix on lower quadrant as shown in Figure 1 and not on bottom of pipe.
- To prevent overheating, be sure the location of the heating cable is planned so that the active heating zone will not extend into the component. Read the kit installation instructions and plan the component location before permanently attaching the cable to the pipe.
- Ensure that the active heating zones are located where heat is required i.e. on the pipe.
- Thermally insulate and weatherproof to specification.
- When installing Raychem constant wattage parallel circuit heating cables ensure that they do not overlap or cross.

**Figure 1**




**Raychem Attachment tapes:**

GT66 Self-adhesive glass cloth tape  
General purpose tape. Not for stainless-steel pipes or for installation temperatures  $<4^{\circ}\text{C}$ .

GS54 Self-adhesive glass cloth tape  
Recommended for use on stainless-steel and cupra-nickel surfaces and for installation temperatures  $<4^{\circ}\text{C}$ .

**Figure 2**



ATE-180 Aluminium tape  
Use only if the design requires it.

### 3.4.2 Spiral tracing

- Alternative spiralling methods are shown in Figures 2a and 2b.
- Only spiral heating cable on pipe when called for by design.
- To prevent overheating, be sure the location of the heating cable is planned so that the active heating zone will not extend into the component. Read the kit installation instructions and plan the component location before permanently attaching the cable to the pipe.
- Ensure that the active heating zones are located where heat is required i.e. on the pipe.


#### Spiral Pitch Table (mm).

NB (mm)	NPS (inches)	Spiral Ratio – Metres of cable per metre of pipe				
		1.1	1.2	1.3	1.4	1.5
25	1	250	170	140	110	100
32	1 <sup>1/4</sup>	310	210	170	140	130
40	1 <sup>1/2</sup>	350	240	190	160	140
50	2	430	300	240	200	180
65	2 <sup>1/2</sup>	520	360	290	240	210
80	3	630	430	350	290	260
90	3 <sup>1/2</sup>	720	490	390	330	290
100	4	800	560	440	370	330
125	5	990	680	550	460	400
150	6	1180	810	650	550	480
200	8	1520	1050	840	710	620

**Example:** For pipe of 80 mm NB (3" NPS) requiring 1.3 metres of heating cable per metre of pipe, pitch is 350 mm.

- Thermally insulate and weatherproof to specifications.
- When installing Raychem constant wattage parallel circuit heating cables ensure that they do not overlap or cross.


**Figure 2a**



Heating cable length = pipe length x spiral ratio  
Refer to design specification for spiral ratio

- Step 1 Make starting loop as shown
- Step 2 Grasp loop and wind around pipe
- Step 3 Space evenly and attach to pipe  
Thermally insulate and weatherproof to specification

**Figure 2b**



Refer to design specification for spiral pitch

Mark the pipe at the spiral pitch or use a simple length gauge

Fix the heating cable as installation progresses  
Thermally insulate and weatherproof to specification

### 3.5 Cutting the heating cable

- Cut the heating cable to length after it is attached to the pipe.  
Before cutting it, confirm the tracing allowance as per Sections 3.3 and 3.6.

## 3.6 Typical installation details


- Typical installation details for fixing heating cable to pipe fittings are shown hereafter.

### General notes:

- Trace pipe fittings as shown to allow easy maintenance.
- Consult the design specification for the tracing requirements for fittings and supports.
- Follow the recommendations for cutting and stripping heating cables; they are included in the component installation instructions.

### 3.6.1 Valve

Figure 3




The drawing shows the general installation method. The heating cable configuration will vary for different valve shapes and heating cable lengths.

- Refer to design specification for additional heating cable length.
- Fix with self-adhesive glass cloth tape.
- Thermally insulate and weatherproof to specification (including valve stem).
- **No overlapping or crossing of the heating cable.**

### 3.6.2 Elbow


Figure 4



- Fix heating cable to outside (long) radius of elbow  
Fix with self-adhesive glass cloth tape  
Thermally insulate and weatherproof to specification
- **No overlapping or crossing of the heating cable.**


### 3.6.3 Flange

Figure 5



- Additional heating cable is 2 times diameter of pipe  
Fix with self-adhesive glass cloth pipe  
Thermally insulate and weatherproof to specification
- **No overlapping or crossing of the heating cable.**

### 3.6.4 Pipe bar hanger




- **Do not** clamp heating cable with support. Heating cable must be over the support
- No additional heating cable is required for bar or rod pipe hangers unless called for in the design specification, then use loop length specified
- Fix with self-adhesive glass cloth tape
- Thermally insulate and weatherproof to specification
- **No overlapping or crossing of the heating cable.**




### 3.6.5 Pipe support shoe

Figure 7

Side view



View from under



- Refer to design specification for additional heating cable length
- Fix with self-adhesive glass cloth tape
- Thermally insulate and weatherproof to specification
- **No overlapping or crossing of the heating cable.**

## 4 COMPONENTS INSTALLATION

### General notes:

Use the Design Specification to select required components.

Raychem component kits (including power connections, splices and end seals) must be used to satisfy Standards and Approval Body requirements.

Installation instructions included in the kit must be followed, including those for preparation of the heating cable conductors for connections. Before assembly, use the guide given in the instructions to ensure that the kit is correct for the heating cable and environment.

- Raychem constant wattage parallel circuit heating cables are parallel circuit design. **Do not** twist the conductors together as this will result in a short circuit.

### 4.1 Components required


- For the installation of all components refer to the relevant component installation instructions.
- Required for each heating cable run:  
Power connection and insulation entry kit  
End seal.
- As required:  
Accessories (pipe straps, fixing tape, support brackets, labels, etc)

### 4.2 Component installation hints


- On horizontal pipes locate junction boxes below pipe wherever possible.
- Locate junction boxes for easy access but not exposed to mechanical abuse.
- Position junction boxes so that power cable and heating cable entries do not point upwards.
- Fix lids in place where access not required.
- Confirm junction box stopping plugs are correct for application and fixed firmly in place.

- Route heating cable from junction box to insulation entry so as to avoid possible mechanical damage.
- **Do not** strain heating cable as it exits/enters junction boxes and insulation entries.
- Ensure heating cable is fixed above pipe straps such as used for junction box support brackets.
- Fix all low profile components in place with self-adhesive glass cloth tape.


### 4.3 Typical Installations



#### Ambient Sensing System



#### Line Sensing System



#### Line Sensing System with Temperature Limit

## 5 THERMOSTATS

- Raychem constant wattage parallel circuit heating cables ALWAYS require temperature control.
- The FMT and FHT range of heating cables may be used in an electric surface heating system in a hazardous area that meets the requirements of a stabilised design within the constraints of the certification.
- If a stabilised design cannot be achieved, then a thermostat control with a limiter that complies with the appropriate requirements shall be used. The limiter shall be set to ensure that the maximum temperature of the surface to be heated does not exceed that specified in the certification for a given output in a specific temperature classification.
- ALWAYS install the correct and suitably approved thermostat as detailed in the design specification.
- Follow the installation instructions supplied with the thermostat. Use the proper wiring diagram for the heating cable layout and control method desired.

## 6 THERMAL INSULATION AND MARKING

### 6.1 Pre-insulation checks

- Visually inspect the heating cable and components for correct installation and damage. (See Section 10 if damaged.)
- Insulation resistance (Megger) testing (as per Section 8) is recommended prior to covering the pipe with thermal insulation.


### 6.2 Insulation installation hints

- Correct temperature maintenance requires properly installed and dry thermal insulation.
- Thermally insulate and weatherproof to design specification.
- Check insulation type and thickness against the design specification.
- To minimize potential heating cable damage, insulate as soon as possible after tracing.
- Check that all pipework, including fittings, wall penetrations and other areas, has been completely insulated.
- Ensure that heating cable is not damaged during installation of cladding for example by drills, self tapping screws and sharp edges of cladding.
- Check that all insulation entry kits are fitted correctly and sealed.
- Ensure that all places where valve stems, support brackets, thermostat capillaries, etc exit the cladding are sealed.

### 6.3 Marking

- Install warning labels along piping at suitable intervals (3 m intervals recommended) on alternate sides as a warning.
- Mark on outside of insulation the location of heating cable components.

“When the FMT or FHT heating cable is used in hazardous area, install aluminium tag plate LAB-EX-FxT on the power cable at approximately 75mm from the junction box”



## **7 POWER SUPPLY AND ELECTRICAL PROTECTION**

### **7.1 Electrical loading**

Size overcurrent protective devices according to the design specification.

### **7.2 Residual current (earth fault) protection**

Pentair insists on the use of a 30 mA residual current device to provide maximum safety and protection. However, where there is a marked increase in nuisance tripping, a maximum 300 mA residual current device may be used.

For heating cables installed in a hazardous area, the use of residual current devices is normally a condition of their approval.

## **8 HEATING CABLE TESTING**

### **8.1 Recommendations**

Pentair recommends an insulation resistance test before installing heating cable; before installing thermal insulation; prior to initial start-up; and as part of the periodic maintenance. (see Section 9.2).



### **8.2 Test method**

After completing heating cable installation, the insulation resistance between the conductors and the braid or metal pipe should be checked (see Section 6.1) using a 2500 VDC megger™. Minimum readings should be 10 Megohms regardless of the heating cable length. The installer should record the original values for each circuit on the installation record sheet (see page 27).

**Figure 4**

Test A: Test between heating cable and braid

Test B: Test between heating cable braid and pipe





## 9 OPERATION, MAINTENANCE AND PIPE REPAIRS

### 9.1 Heating cable operation

- **Temperature exposure must not exceed that specified in the product literature. Exceeding those limitations will shorten the service life and may permanently damage the heating cable.**
- Pipe insulation must be complete and dry to maintain the correct temperature.

### 9.2 Inspection and maintenance

- Visual inspection: Exposed heating cable and pipe insulation should be checked periodically to make sure that no physical damage has occurred.
- Meggering: The system should be meggered regularly. When meggering the insulation resistance from the main supply panel, it is recommended that the test is performed between L/N (together) and PE. Freeze protection systems should be meggered before the winter months each year (see section 8). Temperature maintenance systems should be tested at least twice a year. Function testing of electrical protection and temperature control systems should be carried out at regular intervals.
- The Periodic Inspection Record on the following pages should be filled out during maintenance of each circuit in your system.

### 9.3 Piping systems repair and maintenance

- Isolate heating cable circuit and protect the heating cable from mechanical or thermal damage during pipe repair work.
- Check heating cable installation after pipe repairs and restore thermal insulation following the recommendations in Section 6. Check correct functioning of electrical protection systems.

## 10 HEATING CABLE DAMAGE

- **Do not repair damaged heating cable.**  
Remove entire damaged section and splice in a new length using the appropriate Raychem components.
- **Replace damaged heating cable at once.**  
Damage allowing moisture and contamination to enter the heating cable may result in arcing earth faults and potential fire hazards.
- Heating cable exposed to fire or flame may cause further fire damage if powered.  
Remove from service at once and replace before re-use.

## 11 TROUBLESHOOTING GUIDE

Refer to the Troubleshooting guide on pages 30-33. If the problem persists after following the guide procedures, contact your Pentair representative immediately.

# INSTALLATION RECORD SHEET

CIRCUIT NO.

INSTALLATION RECORDS FOR:																				
Circuit breaker number																				
Drawing reference number																				
Megger test on pipe before insulating (bypass thermostat if applicable)	Reading																			
	Initial																			
	Date																			
Megger test after insulating (bypass thermostat if applicable)	Reading																			
	Initial																			
	Date																			
Circuit voltage	Panel																			
	Connection terminals																			
Insulation complete and sealed	Initial																			
	Date																			
Locations of low profile components are marked on the cladding	Initial																			
	Date																			

REMARKS & COMMENTS:

# INSPECTION AND MAINTENANCE RECORD SHEET

CIRCUIT NO.							

MAINTENANCE CHECKS FOR:		MONTH: _____ YR.: _____					
No signs of overheating, moisture, or corrosion, etc.	Initial						
	Date						
In connection systems Heating cable and cable glands tight Connection terminals tight Earth connection tight Insulation in good condition	Initial						
	Date						
Thermostats set properly and capillaries are protected	Initial						
	Date						



# TROUBLESHOOTING GUIDE

Symptom	Probable Causes
Overcurrent protection trips or blows.	Electrical fault at: a damaged heating cable b faulty splices or tees c end seal d connection
	Circuit oversized
	Start-up below design temperature
	Defective electrical protection

Symptom	Probable Causes
RCD trips.	Earth fault at: a damaged heating cable b faulty splices or tees c end seal d connection
	Excessive moisture in: a junction boxes b splices and tees c end seals
	High leakage currents due to a combination of excessive lengths of power cable and heating cable.
	Mains borne disturbances
	Defective RCD

	<b>Corrective Actions</b>
	Investigate and remedy (see note 1):
	Resize or redesign
	a redesign for lower start-up temperatures. b preheat pipe from alternative heat source to within exposure temperatures given in Product Data Sheets. c Energize part of circuit
	Ersetzen

	<b>Corrective Actions</b>
	Investigate and remedy (see note 1):
	Dry out and reseal or remake immediately. Perform insulation resistance test. (10 MΩ minimum)
	Redesign
	Redesign distribution, guidance is available from Raychem
	Replace.

Symptom	Probable Causes
No power output.	Loss of supply voltage due to: a overcurrent or residual current protection operating b loose terminals in junction box c loss of supply cable continuity (e.g., open circuited from damage)
	Control thermostat is connected in the normally open position or limit thermostat is tripped
	High resistance connection at: a junction box terminals b splices and tees

Symptom	Probable Causes
Low pipe temperature	Wet thermal insulation
	Design error
	Incorrect setting or operation of controls e.g., thermostats.

**Note:**

Locate faults by the following steps:


- 1 Visually inspect the power connections, splices and end seals for correct installation.
- 2 Look for signs of damage at:
  - a) Valves, pumps, flanges and supports.
  - b) Areas where repairs or maintenance work has been carried out.
- 3 Look for crushed or damaged insulation and cladding along the pipe..




	<b>Corrective Actions</b>
	Restore supply voltage a following A and B (page 26) b re-tighten terminals NB: If excessive heating has occurred due to high resistance, replace terminals or crimps c locate damage and repair
	Reconnect to normally closed position
	Locate and remedy by: a retighten b repair NB: If excessive heating has occurred due to high resistance, replace terminals or crimps

	<b>Corrective Actions</b>
	Remove and replace with dry insulation of correct specification and ensure complete weatherproofing
	a check with competent authority for design conditions b modify to meet Raychem recommendations
	Repair or reset to correct level of operation

- 4 If after 1, 2 and 3 above the fault has not been located, then either:
- a) Consult Pentair for further assistance.
  - b) Where local practices and conditions allow (e.g., non hazardous areas) isolate one section of heating cable from another by cutting in half and testing (e.g., Insulation Resistance) both halves until general area of damage is found.
- Remove insulation and expose fault.





**BELGIË / BELGIQUE**

Tel. +32 16 21 35 02  
Fax +32 16 21 36 04  
salesbelux@pentair.com

**BULGARIA**

Tel./fax +359 56 86 68 86  
fax +359 56 86 68 86  
salesee@pentair.com

**ČESKÁ REPUBLIKA**

Tel. +420 241 009 215  
Fax +420 241 009 219  
czechinfo@pentair.com

**DANMARK**

Tel. +45 70 11 04 00  
Fax +45 70 11 04 01  
salesdk@pentair.com

**DEUTSCHLAND**

Tel. 0800 1818205  
Fax 0800 1818204  
salesde@pentair.com

**ESPAÑA**

Tel. +34 902 125 307  
Fax +34 91 640 29 90  
ptm-sales-es@pentair.com

**FRANCE**

Tél. 0800 906045  
Fax 0800 906003  
salesfr@pentair.com

**HRVATSKA**

Tel. +385 1 605 01 88  
Fax +385 1 605 01 88  
salesee@pentair.com

**ITALIA**

Tel. +39 02 577 61 51  
Fax +39 02 577 61 55 28  
salesit@pentair.com

**LIETUVA/LATVIJA/EESTI**

Tel. +370 5 2136633  
Fax +370 5 2330084  
info.baltic@pentair.com

**MAGYARORSZÁG**

Tel. +36 1 253 7617  
Fax +36 1 253 7618  
saleshu@pentair.com

**NEDERLAND**

Tel. 0800 0224978  
Fax 0800 0224993  
salesnl@pentair.com

**NORGE**

Tel. +47 66 81 79 90  
Fax +47 66 80 83 92  
salesno@pentair.com

**ÖSTERREICH**

Tel. 0800 297410  
Fax 0800 297409  
info-ptm-at@pentair.com

**POLSKA**

Tel. +48 22 331 29 50  
Fax +48 22 331 29 51  
salespl@pentair.com

**REPUBLIC OF KAZAKHSTAN**

Tel. +7 495 926 18 85  
Fax +7 495 926 18 86  
saleskz@pentair.com

**РОССИЯ**

Тел. +7 495 926 18 85  
Факс +7 495 926 18 86  
salesru@pentair.com

**SERBIA AND MONTENEGRO**

Tel. +381 230 401 770  
Fax +381 230 401 770  
salesee@pentair.com

**SCHWEIZ / SUISSE**

Tel. 0800 551308  
Fax 0800 551309  
info-ptm-ch@pentair.com

**SUOMI**

Puh. 0800 11 67 99  
Telekopio 0800 11 86 74  
salesfi@pentair.com

**SVERIGE**

Tel. +46 31 335 58 00  
Fax +46 31 335 58 99  
salesse@pentair.com

**TÜRKIYE**

Tel. +90 530 977 64 67  
Fax +32 16 21 36 04  
ptm-sales-tr@pentair.com

**UNITED KINGDOM**

Tel. 0800 969013  
Fax 0800 968624  
salesthermaluk@pentair.com



[WWW.PENTAIRTHERMAL.COM](http://WWW.PENTAIRTHERMAL.COM)

All Pentair trademarks and logos are owned by Pentair or its global affiliates. Pentair reserves the right to change specifications without prior notice.

© 2003-2016 Pentair.